




Balancer Wheel Lift, 20-3101-1

REFER TO NEXT SHEET FOR PARTS DESCRIPTION LISTING

Index No.	Part Number	Description	Qty.
1	72-563-1	BALANCER WHEEL LIFT	1
1a	56-85-1	CARRIER ASSEMBLY	1
2	56-84-1-005	CARRIER	1
2a	46-729-2	SPACER BEARING	2
2b	98-508-2	SPRING (NOT SHOWN)	1
2c	76-11-2	NUT-HEX 10-32 ZP (NOT SHOWN)	1
2d	75-436-2	SHCS 10-32 X 1.00 FTHD ZP (TROLLEY SPEED ADJUSTMENT, NOT SHOWN)	1
2e	94-38-2	CABLE TIE (NOT SHOWN)	1
3	74-59-2	HHCS 3/8-16 X .75 FTHD	3
4	130-136-2	BEARING, 3/8 X 7/8	3
5	103-253-005	ARM BEARING, WL CARRIER	1
6	77-297-2	FLAT WASHER 3/8 ZP	5
7	76-159-2	KEPS NUT, 3/8-16 ZP	3
8	74-568-2	BOLT-SHOULDER, 3/8 X 1/4 LG	1
9	74-442-2	HHCS 1/2-13 X .75	4
10	130-237-2	BEARING, 1/2 X 1 3/8	12
11	122-22-1-005	UPPER PLATFORM ASSEMBLY	1
12	75-765-2	SBHCS 1/4-20 X 3/8 (TROLLEY STOP)	2
13	76-500-2	LOCK NUT 1/4-20, NYLON INSERT (TROLLEY STOP)	2
14	13-321-1	LEG ASSEMBLY, INCLUDES	1
14a	113-343-2	BUSHING-FLG, 1/2 X 5/8 X 3/8 L (NOT SHOWN)	6
14b	113-344-2	BUSHING, 1/2 X 5/8 X 3/8 LG (NOT SHOWN)	2
15	13-318-1-005	INNER SCISSOR LEG ASS'Y	1
16	13-320-1-005	OUTER SCISSOR LEG ASS'Y	1
17	74-589-2	SBHCS 1/2-13 X 1.50 ZP	4
18	77-426-2	THRUST WASHER 1/2 X 7/8	4
19	76-333-2	LOCK NUT 1/2-13 NYL INSERT ZP	4
20	112-15-2	SNAP RING-5133-50 OR EQUAL	10
21	135-561-2	CLEVIS PIN, 1/2 X 1	6
22	140-114-1	CYLINDER ASSEMBLY, INCLUDES:	1
22a	121-317-2	ROD END BLOCK (NOT REFERENCED)	1
22b	121-320-2	CYLINDER GUIDE BLOCK (NOT REFERENCED)	1
22c	75-757-2	SHCS 10-32 X 50 (NOT REFERENCED)	2
22d	136-111-2	BREATHER VENT FILTER (NOT REFERENCED)	1
22e	76-128-2	JAM NUT 1/2-20 ZP (NOT REFERENCED)	1
23	140-113-2	CYLINDER	1
24	77-426-2	THRUST WASHER	4
25	76-333-2	LOCK NUT 1/2-13 NYLON INSERT	1
26	74-358-2	SHCS 1/2-13 X 4.00 ZP	1
27	145-318-2	5/32 Y AIR FITTING	2
28	145-492-2	5/32 AIR FITTING	1
29	16-450-2	5/32 AIR TUBE- (NOT SHOWN)	74 IN.
30	112-14-2	SNAP RING 5133-37 OR EQUAL	2
31	135-511-2	CLEVIS PIN 3/8 X 1	1
32	72-609-1-005	BASE WELDMENT	1
32a	75-797-2	1/4-20 X 1.25 SHCS BO (LEVELING SCREW)	6
32b	76-51-2	1/4-20 JAM NUT (LEVELING NUT)	6
33	164-121-1	PEDAL ASSEMBLY	1
34	74-283-2	SBHCS 5/16-18 X .50 FTHD	2
35	103-259-005	VALVE ACTUATOR ARM	1
36	105-681-1-005	PEDAL HOUSING ASSEMBLY	1
36a	105-681-1-005	SHOWN FOR CLARITY	REF
36b	105-681-1-005	SHOWN FOR CLARITY	REF

Index No.	Part Number	Description	Qty.
36c	46-753-2	STANDOFF 8-32 7/16 LG, NYLON (NOT SHOWN)	2
37	69-1539-005	PEDAL COVER	1
38	75-404-2	SBHCS 10-32 X .38 FTHD	2
39	216-132-005	HOOK, PEDAL SPRING (SHOWN FOR CLARITY)	1
40	164-120-011	PEDAL LEVER	1
41	74-481-2	SBHCS 1/4-20 X .50	1
42	77-430-2	FLAT WASHER 1/4 X 7/8	1
43	97-649-2	PEDAL SHAFT	1
44	75-604-2	SHCS 1/4-20 X .63 ZP	5
44a	162-125-2	LOCTITE (NOT SHOWN)	A/R
45	75-394-2	SHCS 10-32 X .50 FTHD	2
46	108-75-2	2 WAY POPPET VALVE	2
47	145-367-2	5/32 ELBOW AIR FITTING	3
48	145-289-2	EXHAUST SILENCER FITTING	1
49	16-450-2	5/32 AIR TUBE, (NOT SHOWN)	7.5 FT.
50	98-514-2	TORSION SPRING (NOT SHOWN)	1
51	98-527-2	COMPRESSION SPRING, 1.65 LG	2
52	76-168-2	ACORN NUT, 10-32 ZP (NOT SHOWN)	1
53	108-162-1	VALVE ASSEMBLY- TWO WAY (INSIDE BALANCER TUB)	1
53a	75-544-2	4-40 X 2.25 PHMS (NOT SHOWN, VALVE HARDWARE)	2
53b	76-366-2	4-40 NYLON INSERT LOCK NUT (NOT SHOWN, VALVE HARDWARE)	2
53c	16-321-2	5/16 AIR TUBE (NOT SHOWN)	20 IN.
54	128-603-2	DECAL, AIR PRESSURE LIMITS (NOT SHOWN)	1
54a	128-1610-2	DECAL, WHEEL LIFT SAFETY (NOT SHOWN)	2
55	136-78-2	AIR FILTER/REGULATOR (BACK OF BALANCER TUB)	1
55a	75-522-2	10-32 X 3/8 SELF-TAPPING SCREW (NOT SHOWN, REGULATOR HARDWARE)	2
56	137-96-1	SUPPLY HOSE ASSEMBLY (NOT SHOWN)	1
57	145-367-2	ELBOW AIR FITTING, 1/8 NPT to 5/32 PTC (BACK OF BALANCER TUB)	1
58	145-493-2	REDUCER AIR FITTING, 5/16 to 5/32 (INSIDE BALANCER TUB)	1
59	43-161-2	PLUG, 1/4 NPT HEX SOCKET, SS (BACK OF BALANCER TUB)	1
60	128-245-2	DECAL, YELLOW & BLACK (NOT SHOWN)	3
61	74-12-2	5/16-18 X 1.00 SHCS	2
62	77-20-2	5/16 FLAT WASHER	2
63	77-434-2	5/16 FLAT RUBBER WASHER	2
64	69-1555-005	WHEEL LIFT AIR LINES COVER	1
65	75-404-2	SBHCS 10-32 X .38	2
66	113-351-2	GROMMET BUSHING (NOT SHOWN,BALANCER TUB ACCESS HOLE)	1