




HS200/201 SENSOR ASSEMBLIES
 REFER TO NEXT SHEET FOR PARTS DESCRIPTION LISTING

Index No.	Part Number	Description	Front Targets	Rear Targets
1	214-115-1	TARGET ASSEMBLY, FRONT PLASTIC LH (Consisting Of:)	1	
OR	214-114-1	TARGET ASSEMBLY, FRONT PLASTIC RH (Not Illustrated)	1	
2	214-112-1	TARGET ASSEMBLY, REAR PLASTIC RH (Consisting Of:)		1
OR	214-113-1	TARGET ASSEMBLY, REAR PLASTIC LH (Not Illustrated)		1
3	105-376-3	HOUSING-FRONT WITH BUMPER	1	
4	105-380-3	HOUSING-REAR WITH BUMPER		1
5	97-485-2	SHAFT, DSP600 TARGET	1	1
6	77-26-2	WASHER, FLAT 3/8 TPA-N	1	1
7	76-34-2	NUT, JAM 3/8-24	1	1
8	51-1714	PLATE, BACKUP FRONT	1	
9	51-1715	PLATE, BACKUP REAR		1
10	75-573-2	FLAT HEAD SHEET METAL SCREW 10-16 X .5	4	4
11	214-109-1	TARGET ASSEMBLY, FRONT 1.86	1	
12	214-104-1	TARGET ASSEMBLY, REAR 2.22		1
13	77-276-2	WASHER-SPRING CURVED #10	3	3
14	76-263-2	NUT, LOCK 10-32 NYLON INSERT	3	3
15	105-369-2	HOUSING, LEVEL TARGET	2	2
16	128-970-2	DECAL, DSP400 TARGET WARNING (Not Illustrated)	1	1
17	221-631-2	TOOL LEVEL, DSP400 TARGET	1	1